

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C

# Preliminary (-80,-322)

16Mb Synchronous DRAM-Die Revision D

## **Features**

· High Performance:

		-80 CL=3	-322 CL=3	-10 CL=3	Units
f <sub>СК</sub>	Clock Frequency	125	100	100	MHz
t <sub>CK</sub>	Clock Cycle	8	10	10	ns
t <sub>AC</sub>	Clock Access Time	6	6	8	ns

- Single Pulsed RAS Interface
- · Fully Synchronous to Positive Clock Edge
- Dual Banks controlled by A11 (Bank Select)
- Programmable CAS Latency: 1.2.3
- Programmable Burst Length: 1,2,4,8,full-page
- Programmable Wrap Sequence: Sequential or Interleave

- Multiple Burst Read with Single Write Option
- Automatic and Controlled Precharge Command
- Data Mask for Read/Write control (x4, x8)
- Dual Data Mask for byte control (x16)
- Auto Refresh (CBR), Self Refresh (SR)
- Suspend Mode and Power Down Mode
- 4096 refresh cycles/64ms
- Random Column Address every CLK (1-N Rule)
- Single 3.3V ± 0.3V Power Supply
- Supports LVTTL I/O interface
- Package: 44 pin 400 mil TSOP-Type II (x4,x8) 50 pin 400 mil TSOP-Type II (x16) 2-High Stack TSOJ

## Description

IBM's 0316409C, 0316809C, and 0316169C are dual bank Synchronous DRAMs organized as addresses A8 and A9 are dropped on the x16 2Mbit x 4 I/O x 2 Bank, 1Mbit x 8 I/O x 2 Bank, and 512Kbit x 16 I/O x 2 Bank, respectively. These devices support LVTTL I/O interface levels. А stacked version of the x 4 component is also offered. These synchronous devices achieve high speed data transfer rates of up to 125 MHz. The chip is fabricated with IBM's advanced 16Mbit CMOS DRAM process technology.

The device is designed to comply with all JEDEC standards set for synchronous DRAM products, both electrically and mechanically. All of the control, address and data input/output circuits are synchronized with the positive edge of an externally supplied clock (CLK).

Internal chip operating modes are defined by combinations of RAS, CAS, WE, and CS and a command decoder initiates the necessary timings for each operation. A twelve bit address bus accepts address data in the conventional RAS/CAS multiplexing style. Eleven row addresses (A0-A10) and a bank select address (A11) are strobed with  $\overline{RAS}$ . Ten column addresses (A0-A9) plus A10 and a bank select address (A11) are strobed with CAS. Column

DataSheet4U.com

address A9 is dropped on the x8 device and column device. Access to the lower or upper DRAM in a stacked device is controlled by  $\overline{CS0}$  and  $\overline{CS1}$ .

Prior to any access operation, the CAS latency, burst length, and burst sequence must be programmed into the device by address inputs A0-A11 during a mode register set cycle. In addition, it is possible to program a multiple burst sequence with single write cycle for write through cache operation.

Operating the two memory banks in an interleave fashion allows random access operation to occur at a higher rate than is possible with standard DRAMs. A sequential and gapless data rate of up to 125 MHz is possible depending on burst length, CAS latency, and speed grade of the device.

Auto Refresh (CBR) and Self Refresh (SR) operation are supported. Refreshing both decks of a stacked device simultaneously is allowed during Self Refresh but all other stacked device operations must be performed on a single deck at a time.

DataShe



## Pin Assignments for Planar Components (Top View)

VE		44 🛛 V <sub>SS</sub>		44 🛛 V <sub>SS</sub>		50 🛛 V <sub>SS</sub>
Ν		43 🗍 NC		43 🛛 DQ7		49 🛛 DQ15
VSS	SQ [] 3	42 🛛 VSSQ	vssq 🛛 3	42 🛛 VSSQ	DQ1 [] 3	48 🛛 DQ14
DC	QO 🛛 4	41 🛛 DQ3	DQ1 [ 4	41 🗍 DQ6	vssq [ 4	47 🛛 VSSQ
VDE	Q [ 5	40 🛛 VDDQ	VDDQ 🛛 5	40 🛛 VDDQ	DQ2 🛛 5	46 🛛 DQ13
Ν	IC [ 6	39 🗍 NC	DQ2 🛛 6	39 🛛 DQ5	DQ3 🛛 6	45 🛛 DQ12
VSS	SQ [] 7	38 🛛 VSSQ	VSSQ 🛛 7	38 🛛 VSSQ	VDDQ [] 7	44 🖞 VDDQ
DC	בז 🛙 8	37 🛛 DQ2	DQ3 🛛 8	37 🗍 DQ4	DQ4 🛛 8	43 🛛 DQ11
VDE	DQ [ 9	36 🛛 VDDQ	VDDQ 🛛 9	36 🛛 VDDQ	DQ5 🛛 9	42 🛛 DQ10
Ν	IC [ 10	35 🗍 NC	NC 🛛 10	35 🗍 NC	VSSQ 🛛 10	41 🛛 VSSQ
Ν	IC [ 11	34 🛛 NC	NC 🛛 11	34 🛛 NC	DQ6 🛛 11	40 🛛 DQ9
V	νe [ 12	33 🛛 DQM	WE 🛛 12	33 🛛 DQM	DQ7 🛛 12	39 🛛 DQ8
	AS [ 13	32 🛛 CLK	CAS 🛛 13	32 🛛 CLK	VDDQ 🛛 13	38 🛛 VDDQ
RA	AS [ 14	31 🛛 СКЕ	RAS 🛛 14	31 🛛 CKE	LDQM 🛛 14	37 🛛 NC
ō	S [ 15	30 🗍 NC	CS 🛛 15	30 🛛 NC	WE 🛛 15	36 🛛 UDQM
A11(B	S) 🛛 16	29 🛛 A9	A11(BS) 🛛 16	29 🛛 A9	CAS 🛛 16	35 🗋 CLK
A	10 🛛 17	28 🗋 A8	A10 🛛 17	28 🛛 A8		34 🛛 СКЕ
1	AO [ 18	27 🗍 A7	A0 🛛 18	27 🗍 A7	CS 🛛 18	33 🗋 NC
	A1 [ 19	26 🛛 A6	A1 🛛 19	26 🛛 A6	A11(BS) 🛛 19	32 🗍 A9
t4U.com	A2 [ 20	25 🗋 A5	A2 🛛 20	25 🗍 A5	A10 🛛 20	31 🗋 A8
	A3 🛛 21	24 🛛 A4	A3 🛛 21	24 🛛 A4	A0 🛛 21	30 🛛 A7
VE	D [ 22	23 🛛 V <sub>SS</sub>		Sheet423 D Vss	A1 [ 22	29 🗋 A6
					A2 🛛 23	28 🛛 A5
					A3 🛛 24	27 🛛 A4
					VDD [ 25	26 🛛 V <sub>SS</sub>
44-	pin Plastic TSOP	(II) 400 mil	44-pin Plastic T	SOP(II) 400 mil	50-pin Plastic TS	6 <b>0P(II)</b> 400 mil
	2Mbit x 4 I/O x 2	Bank	1Mbit x 8 I/0	O x 2 Bank	512Kbit x 16 I	/O x 2 Bank
	IBM0316409C	тз	IBM0316	809CT3	IBM03161	169CT3

## **Pin Description**

CLK	Clock Input	DQ0-DQ15	Data Input/Output
CKE	Clock Enable	DQM, LDQM, UDQM	Data Mask
CS	Chip Select	VDD	Power (+3.3V)
RAS	Row Address Strobe	VSS	Ground
CAS	Column Address Strobe	VDDQ	Power for DQs (+3.3V)
WE	Write Enable	VSSQ	Ground for DQs
A11 (BS)	Bank Select	NC	No Connection
A0 - A10	Address Inputs	—	—

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com



Page 2 of 121

DataSheet4U.com



# Pin Assignments for 2-High Stack Package (Dual CS Pins) (Top View)

					1	
VDD	d 1	$\cap$		44	Ь	V <sub>SS</sub>
NC	₫ 2	$\bigcirc$		43	þ	NC
VSSQ	₫з			42	þ	VSSQ
DQ0	d 4			41	þ	DQ3
VDDQ	₫ 5			40		VDDQ
NC	Цб			39		NC
VSSQ	d 7			38		VSSQ
DQ1	dв			37	þ	DQ2
VDDQ	Цэ			36		VDDQ
NC	d 10	)		35	þ	NC
NC	d 11			34	þ	NC
WE	d 12	2		33		DQM
CAS	<b>[</b> 13	3		32	þ	CLK
RAS	<b>[</b> 14	Ļ		31	þ	CKE
* CS0/NC	[ 15	5		30	þ	NC/CS1 *
A11 (BS)	[ 16	5		29	þ	A9
A10	<b>[</b> 17	,		28	þ	A8
A0	[ 18	3		27		A7
A1	[ 19	)		26		A6
A2	d 20	)		25	þ	A5
A3	C 21			24	þ	A4
VDD	5 <mark>22</mark> 2	Shee	et4U.c	23 011	þ	V <sub>SS</sub>

et4U.com

# 44-pin Plastic TSOJ(II) 400 mil (2Mbit x 4 I/O x 2 Bank) x 2 High IBM03164B9CT3

DataShee

\* CS0 selects the lower DRAM in the stack. \* CS1 selects the upper DRAM in the stack.

## **Pin Description**

CLK	Clock Input	DQ0-DQ3	Data Input/Output
CKE	Clock Enable	DQM	Data Mask
<u>CS0, CS1</u>	Chip Select	VDD	Power (+3.3V)
RAS	Row Address Strobe	VSS	Ground
CAS	Column Address Strobe	VDDQ	Power for DQs (+3.3V)
WE	Write Enable	VSSQ	Ground for DQs
A11 (BS)	Bank Select	NC	No Connection
A0 - A10	Address Inputs	—	_

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataSheet4U.com



## Input/Output Functional Description

Symbol	Туре	Signal	Polarity	Function
CLK	Input	Pulse	Positive Edge	The system clock input. All of the SDRAM inputs are sampled on the rising edge of the clock.
CKE	Input	Level	Active High	Activates the CLK signal when high and deactivates the CLK signal when low. By deacti- vating the clock, CKE low initiates the Power Down mode, Suspend mode, or the Self Refresh mode.
<u>CS,</u> CS0, CS1	Input	Pulse	Active Low	CS (CS0, CS1 for stacked devices) enables the command decoder when low and disables the command decoder when high. When the command decoder is disabled, new commands are ignored but previous operations continue.
RAS, CAS WE	Input	Pulse	Active Low	When sampled at the positive rising edge of the clock, $\overline{CAS}$ , $\overline{RAS}$ , and $\overline{WE}$ define the operation to be executed by the SDRAM.
A11 (BS)	Input	Level	—	Selects which bank is to be active. A11 low selects bank A and A11 high selects bank B.
				During a Bank Activate command cycle, A0-A10 defines the row address (RA0-RA10) when sampled at the rising clock edge. During a Read or Write command cycle, A0-A9 defines the column address (CA0-CA9) when sampled at the rising clock edge.
A0 - A10	Input	Level	_	A10 is used to invoke Auto-Precharge operation. If A10 is high, Auto-Precharge is selected and A11 defines the bank to be precharged (low=bank A, high=bank B). If A10 is low, Auto-Precharge is disabled.
				During a Precharge command cycle, A10 is used in conjunction with A11 to control which bank(s) to precharge. If A10 is high, both bank A and bank B will be precharged regardless of the state of A11. If A10 is low, then A11 is used to define which bank to precharge.
DQ0 - DQ15	Input Output	Level	—	Data Input/Output pins operate in the same manner as on conventional DRAMs.
DQM LDQM UDQM	Input	Pulse	Active Low	The DQ mask (DQM) places the DQ buffers in a high impedance state when sampled high. In Read mode, DQM has a latency of two clock cycles and controls the output buffers consistent with an output enable. In Write mode, DQM has a latency of zero and operates as a word mask by allowing input data to be written if it is low but blocks the write operation if DQM is high.
VDD, V <sub>SS</sub>	Supply	—	—	Power and ground for the input buffers and the core logic.
VDDQ, VSSQ	Supply	—	—	Isolated power supply and ground for the output buffers to provide improved noise immu- nity.
				4

DataShee

et4U.com

DataSheet4U.com

DataSheet4U.com

Page 4 of 121



Part Number	CAS Latencies	l/O Width	l/O Type	Package	Power Supply	Clock Cycle
IBM0316409CT3-80	2,3	x4	LVTTL	400mil Type II TSOP-44	3.3V	8ns
IBM0316409CT3-322	2,3	x4	LVTTL	400mil Type II TSOP-44	3.3V	10ns
IBM0316409CT3-10	1,2,3	x4	LVTTL	400mil Type II TSOP-44	3.3V	10ns
IBM0316809CT3-80	2,3	x8	LVTTL	400mil Type II TSOP-44	3.3V	8ns
IBM0316809CT3-322	2,3	x8	LVTTL	400mil Type II TSOP-44	3.3V	10ns
IBM0316809CT3-10	1,2,3	x8	LVTTL	400mil Type II TSOP-44	3.3V	10ns
IBM0316169CT3-10	1,2,3	x16	LVTTL	400mil Type II TSOP-50	3.3V	10ns

# Ordering Information - 2 High Stacked Devices (Dual CS Pins)

Part Number	CAS Latencies	l/O Width	I/O Type	Package	Power Supply	Clock Cycle
IBM03164B9CT3-10	1,2,3	x4	LVTTL	400mil Type II TSOJ-44 2-High	3.3V	10ns

et4U.com

DataShee

DataSheet4U.com

DataSheet4U.com



©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



## Block Diagram (2Mbit x 4 I/O x 2 Bank)



DataShee

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Page 6 of 121



# Block Diagram (1Mbit x 8 I/O x 2 Bank)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



## Block Diagram (512Kbit x 16 I/O x 2 Bank)



DataShee

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataSheet4U.com

Page 8 of 121



## Block Diagram (2Mbit x 4 I/O x 2 Bank) x 2-High



et4U.com

DataShee

DataSheet4U.com

DataSheet4U.com



©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 9 of 121

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



#### **Power On and Initialization**

The default power on state of the mode register is supplier specific and may be undefined. The following power on and initialization sequence guarantees the device is preconditioned to each user's specific needs.

Like a conventional DRAM, the Synchronous DRAM must be powered up and initialized in a predefined manner. During power on, all VDD and VDDQ pins must be built up simultaneously to the specified voltage no later than any of the input signal voltages. The power on voltage must not exceed VDD+0.3V on any of the input pins or VDD supplies. After power on, an initial pause of 100µs is required followed by a precharge of both banks using the precharge command. To reduce the possibility of data contention on the DQ bus during power on, it is recommended that the DQM pin(s) be held high during the initial pause period. Once both banks have been precharged, a minimum of two Auto Refresh cycles (CBR) must occur before the Mode Register can be programmed. Failure to follow these steps may lead to unpredictable start-up modes.

#### **Programming the Mode Register**

For application flexibility, CAS latency, burst length, burst sequence, and operation type are user defined variables and must be programmed into the SDRAM Mode Register with a single Mode Register Set Command. Contents of the Mode Register can be altered by re-executing the Mode Register Set Command. If the user chooses to modify only a subset of the Mode Register variables, all variables must be redefined when the Mode Register Set Command is issued.

After initial power up, the Mode Register Set Command must be issued before read or write cycles may begin. Both banks must be in a precharged state and CKE must be high at least one cycle before the Mode Register Set Command can be issued. The Mode Register Set Command is activated by the low signals of RAS, CAS, CS and WE at the positive edge of the clock. The address input data during this cycle defines the parameters to be set as shown in the Mode Register Operation table. A new command may be issued on the second clock following the mode register set command.

## **CAS** Latency

CAS latency is a parameter that is used to define the delay from when a Read Command is registered on a rising clock edge to when the data from that Read Command becomes available at the outputs. CAS latency is expressed in terms of clock cycles and can be programmed to a value of 1, 2, or 3 cycles. The value of CAS latency is determined by the speed grade of the device and the clock frequency that is used in the application. A table showing the relationship between the CAS latency, speed grade, and clock frequency appears in the Electrical Characteristics section of this document. Once the appropriate CAS latency has been selected it must be programmed into the mode register after power up. For an explanation of this procedure, see Programming the Mode Register in the previous section.

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Page 10 of 121



# Mode Register Operation (Address Input For Mode Set)



	(	ļ				,	4					•	,												•	į				•		•	(		(				ľ	1	)				•		ļ					
ş			•	•	•			•	•	•			•	•		•		•	•		•	•		•	•		•	•	•		•	2		•	•		•	•	•	•	•		•	•	•	5		•	•	•	•	

n			
v	0	0	Reserved
0	0	1	1
0	1	0	2
0	1	1	3
1	0	0	Reserved
1	0	1	Reserved
1	1	0	Reserved
1	1	1	Reserved

# **Burst Length**

M2	M1	мо	Len	ıgth
IVIZ		IVIU	Sequential	Interleave
0	0	0	1	1
0	0	1	2	2
0	1	0	4	4
0	1	1	8	8
1	0	0	Reserved	Reserved
1	0	1	Reserved	Reserved
1	1	0	Reserved	Reserved
1	1	1	Full Page	Reserved

et4U.com



©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



## **Burst Mode Operation**

Burst mode operation is used to provide a constant flow of data to memory locations (write cycle), or from memory locations (read cycle). There are three parameters that define how the burst mode will operate. These parameters include burst sequence, burst length, and operation mode. The burst sequence and burst length are programmable, and are determined by address bits A0 - A3 during the Mode Register Set command. Operation mode is also programmable and is set by address bits A7 - A10 and BS.

The burst type is used to define the order in which the burst data will be delivered or stored to the SDRAM. Two types of burst sequences are supported, sequential and interleaved. See Table.

The burst length controls the number of bits that will be output after a Read Command, or the number of bits to be input after a Write Command. The burst length can be programmed to have values of 1, 2, 4, 8 or full page (actual page length is dependent on organization: x4, x8, or x16). Full page burst operation is only possible using the sequential burst type.

Burst operation mode can be normal operation or multiple burst with single write operation. Normal operation implies that the device will perform burst operations on both read and write cycles until the desired burst length is satisfied. Multiple burst with single write operation was added to support Write Through Cache operation. Here, the programmed burst length only applies to read cycles. All write cycles are single write operations when this mode is selected.

Burst Length	Starting Address (A2 A1 A0)	Sequential Addressing (decimal)	Interleave Addressing (decimal)
2	x x 0	DataShe	0, 1
	x x 1	1, 0	1, 0
4	x 0 0	0, 1, 2, 3	0, 1, 2, 3
	x 0 1	1, 2, 3, 0	1, 0, 3, 2
	x 1 0	2, 3, 0, 1	2, 3, 0, 1
	x 1 1	3, 0, 1, 2	3, 2, 1, 0
8	000	0, 1, 2, 3, 4, 5, 6, 7	0, 1, 2, 3, 4, 5, 6, 7
	001	1, 2, 3, 4, 5, 6, 7, 0	1, 0, 3, 2, 5, 4, 7, 6
	010	2, 3, 4, 5, 6, 7, 0, 1	2, 3, 0, 1, 6, 7, 4, 5
	011	3, 4, 5, 6, 7, 0, 1, 2	3, 2, 1, 0, 7, 6, 5, 4
	100	4, 5, 6, 7, 0, 1, 2, 3	4, 5, 6, 7, 0, 1, 2, 3
	101	5, 6, 7, 0, 1, 2, 3, 4	5, 4, 7, 6, 1, 0, 3, 2
	110	6, 7, 0, 1, 2, 3, 4, 5	6, 7, 4, 5, 2, 3, 0, 1
	111	7, 0, 1, 2, 3, 4, 5, 6	7, 6, 5, 4, 3, 2, 1, 0
Full Page (Note)	nnn	Cn, Cn+1, Cn+2,	Not Supported

#### Burst Length and Sequence

Note: Page length is a function of I/O organization and column addressing.

x4 organization (CA0-CA9); Page Length = 1024 bits

x8 organization (CA0-CA8); Page Length = 512 bits

x16 organization (CA0-CA7); Page Length = 256 bits

et4U.com



www.DataSheet4U.com

Page 12 of 121



## Bank Activate Command

In relation to the operation of a fast page mode DRAM, the Bank Activate command corresponds to a falling RAS signal. The Bank Activate command is issued by holding CAS and WE high with CS and RAS low at the rising edge of the clock. The bank select address, A11 (sometimes referred to as BS), is used to select the desired bank. If BS is low then bank A is activated, if BS is high then bank B is activated. The row address A0 - A10 is used to determine which row to activate in the selected bank. Only banks A and B within a single deck of a 2-High stacked device can be accessed. Simultaneous operation of both decks in a stacked device is not allowed, except during Self Refresh.

The Bank Activate command must be applied before any Read or Write operation can be executed. The delay from when the Bank Activate command is applied to when the first read or write operation can begin must meet or exceed the RAS to CAS delay time ( $t_{RCD}$ ). Once a bank has been activated it must be precharged before another Bank Activate command can be applied to the same bank. The minimum time interval between successive Bank Activate commands to the same bank is determined by the RAS cycle time of the device ( $t_{RC}$ ). The minimum time interval between interleaved Bank Activate commands (Bank A to Bank B and vice versa) is the Bank to Bank delay time ( $t_{RBD}$ ).



et4U.com



et4U.com



#### **Read and Write Access Modes**

After a bank has been activated, a read or write cycle can be executed. This is accomplished by setting  $\overline{RAS}$  high and  $\overline{CAS}$  low at the clock's rising edge after the necessary  $\overline{RAS}$  to  $\overline{CAS}$  delay (t<sub>RCD</sub>). WE must also be defined at this time to determine whether the access cycle is a read operation (WE high), or a write operation (WE low).

The SDRAM provides a wide variety of fast access modes. A single Read or Write Command will initiate a serial read or write operation on successive clock cycles at data rates of up to 125 MHz. The number of serial data bits for each access is equal to the burst length, which is programmed into the Mode Register. Although the burst length is user programmable, the boundary of the burst cycle is restricted to specific segments of the page length.

For example, the 2Mbit x 4 I/O x 2 Bank device has a page length of 1024 bits (defined by CA0-CA9). If a burst length of 4 is programmed into the Mode Register, then the page length is divided into 256 uniquely addressable boundary segments (4-bits each). A 4-bit burst operation will occur entirely from one of the 256 groups beginning with the column address supplied to the device during the Read or Write Command (CA0-CA9). The second, third, and fourth access will also occur within this group segment, however, the burst order is a function of the starting address, the burst sequence, and burst boundary.

The above discussion does not apply when full page burst is programmed into the Mode Register. Full page burst operation is only allowed for the sequential burst sequence and has no address boundaries. The SDRAM device will continue bursting data even after all locations of the page have been accessed. The burst sequence will start at the column address defined during the read or write cycle and will increment sequentially until the highest order column address has been reached. At this point, the burst counter will reset to address 0 and continue to perform burst read or burst write operations sequentially until either a Burst Stop Command is issued, a Precharge Command is issued to the bursting bank, or until a new Read or Write Command is issued.

Similar to Page Mode of conventional DRAMs, a read or write cycle can not begin until the sense amplifiers latch the selected row address information. The refresh period ( $t_{REF}$ ) is what limits the number of random column accesses to an activated bank. A new burst access can be done even before the previous burst ends. The ability to interrupt a burst operation at every clock cycle is supported, this is referred to as the 1-N rule. When the previous burst is interrupted by another Read or Write Command, the remaining addresses are overridden by the new address once the CAS Latency has been satisfied.

Precharging an active bank after each read or write operation is not necessary providing the same row is to be accessed again. To perform a read or write cycle to a different row within an activated bank, the bank must be precharged and a new Bank Activate command must be issued. When both Bank A and Bank B are activated, interleaved (ping pong) bank Read or Write operations are possible. By using the programmed burst length and alternating the access and precharge operations between the two banks, fast and seamless data access operation among many different pages can be realized. When the two banks are activated, column to column interleave operation can be done between two different pages. Finally, Read or Write Commands can be issued to the same bank or between active banks on every clock cycle.

www.DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 14 of 121

## **Burst Read Command**

The Burst Read command is initiated by having  $\overline{CS}$  and  $\overline{CAS}$  low while holding  $\overline{RAS}$  and  $\overline{WE}$  high at the rising edge of the clock. The address inputs determine the starting column address for the burst, the Mode Register sets type of burst (sequential or interleave) and the burst length (1, 2, 4, 8, full page). The delay from the start of the command to when the data from the first cell appears on the outputs is equal to the value of the  $\overline{CAS}$  latency that is set in the Mode Register.



#### Burst Read Operation (Burst Length = 4, CAS Latency = 1, 2, 3)

et4U.com

DataSheet4U.com



www.DataSheet4U.com

DataShee

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



#### Read Interrupted by a Read

A Burst Read may be interrupted before completion of the burst by another Read Command, with the only restriction being that the interval that separates the commands must be at least one clock cycle. When a burst read operation is interrupted, the remaining addresses of the current burst cycle are overridden starting with the new column address applied with the interrupting Read Command. The data from the first Read Command continues to appear on the DQs until the CAS latency of the interrupting Read Command is satisfied. At this point, the data from the interrupting Read Command will appear on the DQs and continue for the full burst length.



#### **Read Interrupted by a Read** (Burst Length = 4, <u>CAS</u> Latency = 1, 2, 3)

DataSheet4U.com

Page 16 of 121



## **Read Interrupted by a Write**

To interrupt a burst read with a Write Command, DQM must be used to avoid data contention on the data bus by placing the chip output drivers in a high impedance state at least one clock cycle before the Write Command is initiated. To insure the chip output drivers are tri-stated one cycle before the write operation begins, DQM must be activated at least 3 clock cycles before the Write Command and be deactivated in the same clock cycle as the Write Command.



#### **Read Interrupted by a Write** (Burst Length = 4, CAS Latency = 1, 2, 3)

et4U.com

DataShee





#### **Burst Write Command**

The Burst Write command is initiated by having  $\overline{CS}$ ,  $\overline{CAS}$  and  $\overline{WE}$  low while holding  $\overline{RAS}$  high at the rising edge of the clock. The address inputs determine the starting column address. There is no  $\overline{CAS}$  latency required for burst write cycles. Data for the first burst write cycle must be applied on the DQ pins on the same clock cycle that the Write Command is issued. The remaining data inputs must be supplied on each subsequent rising clock edge until the burst length is completed. When the burst has finished, any additional data supplied to the DQ pins will be ignored.



## Burst Write Operation (Burst Length = 4, CAS Latency = 1, 2, 3)

## Write Interrupted by a Write

A burst write operation may be interrupted before completion of the burst. When a burst write cycle is interrupted by a new Write Command, the remaining addresses of the initial write cycle are overridden starting with the new column address applied with the interrupting Write Command. Data will be written into the device until the programmed burst length of the last write command is satisfied.



#### Write Interrupted by a Write (Burst Length = 4, $\overline{CAS}$ Latency = 1, 2, 3)

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee



Page 18 of 121

et4U.com



#### Write Interrupted by a Read

A Read Command will interrupt a burst write operation on the same clock cycle that the Read Command is registered. The DQs must be in the high impedance state at least one cycle before the interrupting read data appears on the outputs to avoid data contention. When the Read Command is registered, any residual data from the burst write cycle will be ignored. Data that is presented on the DQ pins before the Read Command is initiated will actually be written to the memory.



08J3348 GA15-5285-04

1/98

DataSheet4U.com

www.DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataSheet4U.com

et4U.com

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



## **Burst Stop Command**

Once a burst read or write operation has been initiated, there exist several methods in which to terminate the burst operation prematurely. These methods include using another Read or Write Command to interrupt an existing burst operation, using a Precharge Command to interrupt a burst cycle and close the active bank, or using the Burst Stop Command to terminate the existing burst operation but leave the bank open for future Read or Write Commands to the same page of the active bank. When interrupting a burst with another Read or Write Command care must be taken to avoid DQ contention. The Burst Stop Command, however, has the fewest restrictions making it the easiest method to use when terminating a burst operation before it has been completed.

The Burst Stop Command is defined by having  $\overline{RAS}$  and  $\overline{CAS}$  high with  $\overline{CS}$  and  $\overline{WE}$  low at the rising edge of the clock. When using the Burst Stop Command during a burst read cycle, the data DQs go to a high impedance state after a delay which is equal to the  $\overline{CAS}$  Latency set in the Mode Register.



## Termination of a Burst Read Operation (Burst Length > 4, CAS Latency = 1, 2, 3)

When a Burst Stop Command is issued during a burst write operation, only data presented prior to the Burst Stop command will be written into the device. Any data presented to the device coincident with the Burst Stop command or later will be ignored.

DataShe





#### **Termination of a Burst Write Operation** (Burst Length =X, **CAS** Latency = 1, 2, 3)

## **Auto-Precharge Operation**

Before a new row in an active bank can be opened, the active bank must be precharged using either the Precharge Command or the auto-precharge function. When a Read or a Write Command is given to the SDRAM, the CAS timing accepts one extra address, column address A10, to allow the active bank to automatically begin precharge at the earliest possible moment during the burst read or write cycle. If A10 is low when the Read or Write Command is issued, then normal Read or Write burst operation is executed and the bank remains active at the completion of the burst sequence. If A10 is high when the Read or Write Command is issued, then the auto-precharge function is engaged. During auto-precharge, a Read Command will execute as normal with the exception that the active bank will begin to precharge immediately and may finish before all burst read cycles have been completed. This feature allows the precharge operation to be partially or completely hidden during the burst read cycles (dependent upon burst length) thus improving system performance for random data access. Auto-precharge can also be implemented during Write commands.

A Read or Write Command without auto-precharge can be terminated in the midst of a burst operation. However, a Read or Write Command with auto-precharge can not be interrupted by a command to the same bank. Therefore use of a Read, Write, Precharge, or Burst Stop Command to the same bank is prohibited during a read or write cycle with auto-precharge until the entire burst operation is completed.

If A10 is high when a Read Command is issued, the Read with auto-precharge function is initiated. Once the precharge operation has started the bank cannot be reactivated until an asynchronous delay time equal to  $t_{\rm RP}$  +  $t_{\rm DPL}$ , expressed in nanoseconds rather than clocks, has been satisfied. It should be noted that the device will not respond to the Auto-Precharge Command if the device is programmed for full page burst read or write cycles.

et4U.com

)ataSheet4U.com



©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataShe





#### Burst Read with Auto-Precharge (Burst Length = 4)

et4U.com

DataSheet4U.com

Although a Read Command with auto-precharge can not be interrupted by a command to the same bank, it can be interrupted by a Read or Write Command to the other bank. The auto-precharge function will begin normally with the issuing command.

## Burst Read with Auto-precharge Interrupted by Read (Burst Length = 4, CAS Latency = 2, 3)



DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. DataShee



DataSheet4U.com

Page 22 of 121

www.DataSheet4U.com



If interrupting a Read Command with auto-precharge with a Write Command, DQM must be used to avoid DQ contention.



#### Burst Read with Auto-precharge Interrupted by Write (Burst Length = 8, CAS Latency = 2)

If A10 is high when a Write Command is issued, the Write with auto-precharge function is initiated. The bank undergoing auto-precharge can not be reactivated until t<sub>DPL</sub> and t<sub>RP</sub> are satisfied. This is referred to as t<sub>DAL</sub>, Data-in to Active delay ( $t_{DAL} = t_{DPL} + t_{BP}$ ), and is an asynchronous delay time during auto-precharge.



#### Burst Write with Auto-Precharge (Burst Length = 2)

DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

www.DataSheet4U.com

DataShee

DataSheet4U.com

Page 23 of 121



Similar to the Read Command, a Write Command with auto-precharge can not be interrupted by a command to the same bank. It can be interrupted by a Read or Write Command to the other bank, however. The auto-precharge function is unaffected by the interrupting command and will begin as normally scheduled according to burst length.





et4U.com

DataShee

# Burst Write with Auto-Precharge Interrupted by Read (Burst Length = 4, CAS Latency = 3)





## **Precharge Command**

The Precharge Command is used to precharge or close a bank that has been activated. The Precharge Command is triggered when CS, RAS and WE are low and CAS is high at the rising edge of the clock. The Precharge Command can be used to precharge each bank separately or both banks simultaneously. Two address bits A10 and A11 (BS) are used to define which bank(s) is to be precharged when the command is issued.

#### Bank Selection for Precharge by Address Bits

A10	BS(A11)	Precharged Bank(s)
LOW	LOW	Bank A only
LOW	HIGH	Bank B only
HIGH	DON'T CARE	Both Banks A and B

For read cycles, the Precharge Command may be applied consistent with the  $\overline{CAS}$  Latency set in the Mode Register. The data DQs go to a high impedance state after a delay which is equal to the latency, similar to a Burst Stop Command. Refer to the following figures.

For write cycles, however, a delay must be satisfied from the start of the last burst write cycle until the Precharge Command can be issued. This delay is known as t<sub>DPL</sub>, Data-in to Precharge delay.

et4U.com

After the Precharge Command is issued, the precharged bank must be reactivated before a new read or write access can be executed. The delay between the Precharge Command and the Activate Command must be greater than or equal to the Precharge time (t<sub>BP</sub>).

DataShee





## Burst Read followed by Precharge Command (Burst Length = 4, CAS Latency = 3, -80, -10)



Burst Read followed by Precharge Command (Burst Length = 4, TAS Latency = 3, -322) Т0 Τ1 T2 ΤЗ Τ4 Τ5 T6 Τ7 Τ8 CLK READ Ax0 NOP NOP NOP NOP NOP NOP NOP COMMAND Precharge . \* t<sub>RP</sub>  $\overline{CAS}$  latency = 3 DOUT Ax<sub>0</sub> DOUT Ax<sub>1</sub> DOUT Ax2 DOUT Ax3 t<sub>CK3,</sub> DQs ı ı. ı ı (-322)\* Bank can be reactivated at completion of t<sub>BP</sub>.

DataShee

et4U.com

DataSheet4U.com





## Burst Write followed by Precharge Command (Burst Length = 2, CAS Latency = 2)

et4U.com

DataSheet4U.com

DataShee







## Burst Write followed by Precharge Command (Burst Length = 2, CAS Latency = 3)

★ Bank can be reactivated at completion of t<sub>DAL</sub> (t<sub>DPL</sub> + t<sub>RP</sub>)

DataSheet4U.com

Page 28 of 121



#### **Precharge Termination**

The Precharge Command may be used to terminate either a burst read or burst write operation. When the Precharge command is issued, the burst operation is terminated and bank precharge begins. For burst read operations, valid data will continue to appear on the data bus as a function of CAS Latency.

#### Burst Read Interrupted by Precharge (Burst Length = 8, CAS latency = 1)



et4U.com

DataSheet4U.com

## Burst Read Interrupted by Precharge (Burst Length = 8, TAS latency = 2)



\* Bank can be reactivated at completion of  $t_{RP}$ .

Burst is terminated two clocks after the Precharge command, consistent with  $\overrightarrow{\text{CAS}}$  Latency.

DataSheet4U.com



www.DataSheet4U.com

DataShee





★ Bank can be reactivated at completion of t<sub>RP</sub>.

Burst is terminated three clocks after the Precharge command, consistent with  $\overline{\text{CAS}}$  Latency.



★ Bank can be reactivated at completion of t<sub>RP</sub>.

Burst is terminated three clocks after the Precharge command, consistent with  $\overrightarrow{\text{CAS}}$  Latency.

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. 08J3348 GA15-5285-04 1/98

www.DataSheet4U.com

Page 30 of 121

IEM	IBM0316409C IBM0316809C IBM0316169C
Preliminary (-80,-322)	IBM03164B9C 16Mb Synchronous DRAM-Die Revision D

Burst write operations will be terminated by the Precharge command. However, write data written to the device prior to the Precharge command may be stored incorrectly and is a function of  $\overline{CAS}$  latency and  $t_{DPL}$ .

When  $\overline{CAS}$  latency is set to equal 1 or 2 or when set to 3 with  $t_{DPL} = 1$  clock, the last write data that will be properly stored in the device is that write data that is presented to the device on the clock cycle prior to the Precharge command. The write data presented during the Precharge command will not be written.



#### **Precharge Termination of a Burst Write** (Burst Length = 8, CAS Latency = 1)



DataSheet4U.com

et4U.com



©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 31 of 121

www.DataSheet4U.com

DataSheet4U.com

DataShee





## Precharge Termination of a Burst Write (Burst Length = 8, CAS Latency = 3

When  $\overline{\text{CAS}}$  latency is set to equal 3 and  $t_{\text{DPL}} = 2$  clocks, the last write data that will be properly stored in the device is that write data that is presented to the device two clocks prior to the Precharge command. The write data presented during the clock cycle prior to the Precharge command may be stored incorrectly. To prevent the writing of invalid data to the device, DQM must be asserted high one clock cycle prior to the Precharge command to mask the invalid write data.



#### Precharge Termination of a Burst Write (Burst Length = 8, CAS Latency = 3)

#### DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 32 of 121



## Automatic Refresh Command (CAS Before RAS Refresh)

When  $\overline{CS}$ ,  $\overline{RAS}$  and  $\overline{CAS}$  are held low with CKE and  $\overline{WE}$  high at the rising edge of the clock, the chip enters the Automatic Refresh mode (CBR). Both banks of the SDRAM must be precharged and idle for a minimum of the Precharge time (t<sub>RP</sub>) before the Auto Refresh Command (CBR) can be applied. For a stacked device, only one deck at a time can be refreshed using Automatic Refresh Mode. An address counter, internal to the device, supplies the bank address during the refresh cycle. No control of the external address pins is required once this cycle has started.

When the refresh cycle has completed, both banks of the SDRAM will be in the precharged (idle) state. A delay between the Auto Refresh Command (CBR) and the next Activate Command or subsequent Auto Refresh Command must be greater than or equal to the RAS cycle time ( $t_{RC}$ ).

## Self Refresh Command

The SDRAM device has a built-in timer to accommodate Self Refresh operation. The Self Refresh Command is defined by having  $\overline{CS}$ ,  $\overline{RAS}$ ,  $\overline{CAS}$  and CKE held low with  $\overline{WE}$  high at the rising edge of the clock. Once the Command is registered, CKE must be held low to keep the device in Self Refresh mode. When the SDRAM has entered Self Refresh mode all of the external control signals, except CKE, are disabled. The clock is internally disabled during Self Refresh Operation to save power. The user may halt the external clock while the device is in Self Refresh mode, however, the clock must be registered asynchronously by bringing CKE high. After CKE is brought high, an internal timer is started to insure CKE is held high for approximately 10ns before registering the Self Refresh exit command. The purpose of this circuit is to filter out noise glitches on the CKE input which may cause the SDRAM to erroneously exit Self Refresh operation. Once the Self Refresh command is registered, a delay equal to the RAS cycle time (t<sub>RC</sub>) must be satisfied before any new command can be issued to the device. CKE must remain high for the entire Self Refresh exit period (t<sub>SREX</sub>) and commands must be gated off with  $\overline{CS}$  held high. Alternatively, NOP commands may be registered on each positive clock edge during the Self Refresh exit interval. (See Self Refresh Exit figures.) When using Self Refresh, both decks of a stacked device may be refreshed at the same time.





#### Self Refresh Exit (Commands Gated Off with CS High)

DataSheet4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataShe





#### Self Refresh Exit (Commands Gated Off with NOP Commands)

# et4U.com

#### Data Mask

DataSheet4U.com

The SDRAM has a Data Mask function that can be used in conjunction with data read and write cycles. When the Data Mask is high during a write cycle, the write operation is prohibited immediately (zero clock latency). If the Data Mask is activated during a read cycle, the data outputs are disabled and become high impedance after a two clock delay, independent of CAS latency.

## Data Mask Activated During a Read Cycle (Burst Length = 4, CAS Latency = 1)



DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 34 of 121



## **No Operation Command**

The No Operation Command should be used in cases when the SDRAM is in a idle or a wait state. The purpose of the No Operation Command is to prevent the SDRAM from registering any unwanted commands between operations. A No Operation Command is registered when  $\overrightarrow{CS}$  is low with  $\overrightarrow{RAS}$ ,  $\overrightarrow{CAS}$ , and  $\overrightarrow{WE}$  held high at the rising edge of the clock. A No Operation Command will not terminate a previous operation that is still executing, such as a burst read or write cycle.

## **Deselect Command**

The Deselect Command performs the same function as a No Operation Command. Deselect Command occurs when CS is brought high, the RAS, CAS, and WE signals become don't cares.

#### **Power Down Mode**

In order to reduce standby power consumption, two power down modes are available: Precharge and Active Power Down mode. To enter Precharge Power Down mode, all banks must be precharged and the necessary Precharge delay (t<sub>RP</sub>) must occur before the SDRAM can enter the Power Down mode. If a bank is activated but not performing a Read or Write operation, Active Power Down mode will be entered. (Issuing a Power Down Mode Command when the device is performing a Read or Write operation causes the device to enter Clock Suspend mode. See the following section.) Once the Power Down mode is initiated by holding CKE low, all of the receiver circuits except CLK and CKE are gated off. The Power Down mode does not perform any refresh operations, therefore the device can't remain in Power Down mode longer than the Refresh period (t<sub>REF</sub>) of the device.

The Power Down mode is exited by bringing CKE high. A one clock delay after the registration of CKE high is required for the SDRAM to exit the Power Down mode.

DataShe

et4U.com



IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



#### **Clock Suspend Mode**

During normal access mode, CKE is held high enabling the clock. When CKE is registered low while at least one of the banks is active, Clock Suspend Mode is entered. The Clock Suspend mode deactivates the internal clock and suspends or "freezes" any clocked operation that was currently being executed. There is a one clock delay between the registration of CKE low and the time at which the SDRAM's operation suspends. While in Clock Suspend mode, the SDRAM ignores any new commands that are issued. The Clock Suspend mode is exited by bringing CKE high. There is a one clock cycle delay from when CKE returns high to when Clock Suspend mode is exited.

When the operation of the SDRAM is suspended during the execution of a Burst Read operation, the last valid data output onto the DQ pins will be actively held valid until Clock Suspend mode is exited.



#### Clock Suspend During a Read Cycle (Burst Length = 4, CAS latency = 2)

If Clock Suspend mode is initiated during a burst write operation, then the input data is masked and ignored until the Clock Suspend mode is exited.



## Clock Suspend During a Write Cycle (Burst Length = 4, CAS Latency = 2)

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShe



Page 36 of 121


### Command Truth Table (Notes: 1)

	Cł	ΚE									
Function	Previous Cycle	Current Cycle	CS	RAS	CAS	WE	DQM	A11	A10	A9 - A0	Notes
Mode Register Set	н	х	L	L	L	L	х		OP C	ode	
Auto (CBR) Refresh	н	Н	L	L	L	н	х	х	х	х	
Entry Self Refresh	н	L	L	L	L	н	х	х	х	х	
Exit Self Refresh	L	Н	Н	х	х	х	х	х	х	х	
Single Bank Precharge	н	Х	L	L	н	L	х	BS	L	х	2
Precharge all Banks	Н	Х	L	L	н	L	х	х	Н	х	
Bank Activate	н	Х	L	L	н	н	х	BS	Rov	v Address	2
Write	н	Х	L	н	L	L	х	BS	L	Column	2
Write with Auto-Precharge	н	Х	L	н	L	L	х	BS	н	Column	2
Read	н	Х	L	н	L	н	х	BS	L	Column	2
Read with Auto-Precharge	н	Х	L	н	L	н	х	BS	н	Column	2
Burst Termination	н	Х	L	н	н	L	х	х	х	х	3
No Operation	н	Х	Datas	Sheet4U	.com	н	х	х	х	х	
Device Deselect	н	Х	Н	х	х	Х	х	х	х	x	
Clock Suspend/Standby Mode	L	Х	х	х	х	х	х	х	х	х	4
Data Write/Output Enable	н	Х	х	х	х	х	L	х	х	х	5
Data Mask/Output Disable	Н	Х	х	х	х	х	н	х	х	х	5
Power Down Mode Entry	x	L	х	х	х	х	х	х	х	х	6, 7
Power Down Mode Exit	х	Н	х	х	х	х	х	х	Х	х	6, 7

1. All of the SDRAM operations are defined by states of CS, WE, RAS, CAS, and DQM at the positive rising edge of the clock.For stacked devices: only one deck can be operated at once, except during Self Refresh.

2. Bank Select (BS), if BS = 0 then bank A is selected, if BS = 1 then bank B is selected.

3. During a Burst Write cycle there is a zero clock delay, for a Burst Read cycle the delay is equal to the CAS latency.

4. During normal access mode, CKE is held high and CLK is enabled. When it is low, it freezes the internal clock and extends data Read and Write operations. One clock delay is required for mode entry and exit.

5. The DQM has two functions for the data DQ Read and Write operations. During a Read cycle, when DQM goes high at a clock timing the data outputs are disabled and become high impedance after a two clock delay. DQM also provides a data mask function for Write cycles. When it activates, the Write operation at the clock is prohibited (zero clock latency).

6. All banks must be precharged before entering the Precharge Power Down Mode. If banks are active, Active Power Down Mode is entered. The Power Down Mode does not perform any refresh operations, therefore the device can't remain in this mode longer than the Refresh period (t<sub>REF</sub>) of the device. One clock delay is required for mode entry and exit.

7. If CS is low, then when CKE returns high, no command is registered into the chip for one clock cycle.

www.DataSheet4U.com

DataShee

DataSheet4U.com

DataSheet4U.com





# Clock Enable (CKE) Truth Table

	Cł	<Ε			Con	nmand				
Current State	Previous Cycle	Current Cycle	<del>cs</del>	RAS		WE	A11	A10 - A0	Action	Notes
	Н	х	Х	х	Х	х	Х	x	INVALID	1
	L	Н	Н	х	Х	х	х	х	Exit Self Refresh with Device Deselect	2
	L	н	L	н	Н	н	Х	х	Exit Self Refresh with No Operation	2
Self Refresh	L	Н	L	Н	Н	L	х	x	ILLEGAL	2
	L	Н	L	Н	L	х	х	х	ILLEGAL	2
	L	н	L	L	х	х	х	x	ILLEGAL	2
	L	L	Х	Х	Х	х	Х	х	Maintain Self Refresh	
	Н	х	х	х	Х	х	х	х	INVALID	1
Dawar Dawa	L	Н	Н	х	х	х	х	x	Power Down mode exit, all banks idle	2
Power Down	L	Н	L	Х	Х	х	Х	x	ILLEGAL	2
	L	L	х	х	х	х	х	х	Maintain Power Down Mode	
	Н	н	н	х	х	х				3
	H     H     L     H     X     X       H     H     L     H     X     X         Refer to the Idle State section of the Current State Truth Table	3								
	Н	Н	L	L	Н	х				3
	Н	Н	L	L	LDa	ataShe	et <b>¥</b> U.	comX	CBR Refresh	
	Н	Н	L	L	L	L	OP	, Code	Mode Register Set	4
All Banks Idle	Н	L	Н	Х	Х	х				3
	Н	L	L	Н	х	х			Refer to the Idle State section of the Current State Truth Table	3
	Н	L	L	L	Н	х				3
	Н	L	L	L	L	Н	Х	х	Entry Self Refresh	4
	Н	L	L	L	L	L	OP	Code	Mode Register Set	
	L	Х	Х	х	Х	х	х	x	Power Down	4
	Н	Н	x	x	x	x	x	x	Refer to operations in the Current State Truth Table	
Any State other than	Н	L	х	х	х	x	х	Х	Begin Clock Suspend next cycle	5
listed above	L	Н	х	х	х	х	х	х	Exit Clock Suspend next cycle	
	L	L	Х	Х	Х	Х	х	х	Maintain Clock Suspend	

DataShee

1. For the given Current State, CKE must be low in the previous cycle.

2. When CKE has a low to high transition, the clock and other inputs are re-enabled asynchronously. The minimum setup time for CKE (t<sub>CES</sub>) must be satisfied before any command other than Exit is issued.

3. The address inputs (A11 - A0) depend on the command that is issued. See the Idle State section of the Current State Truth Table for more information.

4. The Power Down Mode, Self Refresh Mode, and the Mode Register Set can only be entered from the all banks idle state.

5. Must be a legal command as defined in the Current State Truth Table.

DataSheet4U.com

et4U.com

www.DataSheet4U.com

Page 38 of 121



# Current State Truth Table (Part 1 of 4) (Notes: 1)

Current State					C	Command		ILLEGAL No Operation No Operation No Operation or Power Down ILLEGAL ILLEGAL Precharge ILLEGAL Start Write; Determine if Auto-Precharge Start Read; Determine if Auto-Precharge No Operation No Operation	Notes
Current State	$\overline{\text{CS}}$	RAS	CAS	WE	A11	A10 - A0	Description	Action	Notes
	L	L	L	L		OP Code	Mode Register Set	Set the Mode Register	2
	L	L	L	Н	х	Х	Auto or Self Refresh	Start Auto or Self Refresh	2, 3
	L	L	н	L	BS	Х	Precharge	No Operation	
	L	L	Н	Н	BS	Row Address	Bank Activate	Activate the specified bank and row	
ldle	L	Н	L	L	BS	Column	Write w/o Precharge	ILLEGAL	4
	L	Н	L	Н	BS	Column	Read w/o Precharge	ILLEGAL	4
	L	Н	Н	L	х	Х	Burst Termination	No Operation	
	L	н	н	Н	Х	Х	No Operation	No Operation	
	н	х	х	Х	х	Х	Device Deselect	No Operation or Power Down	5
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	х	Х	X Auto or Self Refresh ILLEGAL		
Row Active	L	L	Н	L	BS	х	Precharge	Precharge	6
	L	L	н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Row Active	L	Н	L	L	BS	Column	Write	Start Write; Determine if Auto-Precharge	7, 8
	L	Н	L	Н	BS	Column	Read	Start Read; Determine if Auto-Precharge	7, 8
	L	Н	н	L	Х	Х	Burst Termination	No Operation	
	L	Н	Н	Н	х	x Data	No Operation III	No Operation	
	н	х	Х	Х	х	Х	Device Deselect	No Operation	
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	Х	Х	Auto or Self Refresh	ILLEGAL	
	L	L	н	L	BS	Х	Precharge	Terminate Burst; Start the Precharge	
	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Read	L	Н	L	L	BS	Column	Write	Terminate Burst; Start the Write cycle	8, 9
	L	Н	L	Н	BS	Column	Read	Terminate Burst; Start a new Read cycle	8, 9
	L	Н	Н	L	х	Х	Burst Termination	Terminate the Burst	
	L	Н	Н	Н	Х	Х	No Operation	Continue the Burst	
	Н	х	Х	х	х	х	Device Deselect	Continue the Burst	

DataShee

1. CKE is assumed to be active (high) in the previous cycle for all entries. The Current State is the state of the bank that the Command is being applied to.

2. Both Banks must be idle; otherwise it is an illegal action.

3. If CKE is active (high), the SDRAM will start the Auto (CBR) Refresh operation. If CKE is inactive (low), then the Self Refresh mode is entered.

4. The Current State only refers to one of the banks. If BS selects this bank, then the action is illegal. If BS selects the bank not being referenced by the Current State, then the action may be legal depending on the state of that bank.

5. If CKE is inactive (low), then the Power Down mode is entered. Otherwise there is a No Operation.

6. The minimum and maximum Active time (t<sub>RAS</sub>) must be satisfied.

- 7. The  $\overline{RAS}$  to  $\overline{CAS}$  Delay (t<sub>RCD</sub>) must occur before the command is given.
- 8. Column address A10 is used to determine if the Auto Precharge function is activated.
- 9. The command must satisfy any bus contention, bus turn around, and/or write recovery requirements.
- 10. The command is illegal if the minimum bank to bank delay time ( $t_{\text{RRD}}$ ) is not satisfied.

DataSheet4U.com

et4U.com





Preliminary (-80,-322)

#### Current State Truth Table (Part 2 of 4) (Notes: 1)

Current State					С	ommand		Terminate Burst; Start the Read cycle Terminate the Burst Continue the Burst ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL Continue the Burst Continue the Burst ILLEGAL	Notes
Current State	CS	RAS	CAS	WE	A11	A10 - A0	Description	Action	Notes
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	х	Х	Auto or Self Refresh	ILLEGAL	
	L	L	Н	L	BS	Х	Precharge	Terminate Burst; Start the Precharge	
	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Write	L	н	L	L	BS	Column	Write	Terminate Burst; Start a new Write cycle	8, 9
	L	н	L	Н	BS	Column	Read	Terminate Burst; Start the Read cycle	8, 9
	L	н	Н	L	Х	Х	Burst Termination	Terminate the Burst	
	L	н	Н	Н	х	Х	No Operation	Continue the Burst	
	н	Х	Х	Х	х	Х	Device Deselect	Continue the Burst	
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	х	Х	Auto or Self Refresh	ILLEGAL	
Read with Auto-	L	L	Н	L	BS	Х	Precharge	ILLEGAL	4
	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Auto-	L	Н	L	L	BS	Column	Write	ILLEGAL	4
Precharge	L	Н	L	Н	BS	Column	Read	ILLEGAL	4
	L	Н	Н	L	х	Х	Burst Termination	ILLEGAL	
	L	Н	Н	Н	х	Х	No Operation	Continue the Burst	
	н	х	Х	Х	Х	x Da	Device Deselectom	Continue the Burst	
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	Х	Х	Auto or Self Refresh	ILLEGAL	
	L	L	Н	L	BS	Х	Precharge	ILLEGAL	4
Write with	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Auto-	L	н	L	L	BS	Column	Write	ILLEGAL	4
Precharge	L	Н	L	Н	BS	Column	Read	ILLEGAL	4
	L	Н	Н	L	Х	X	Burst Termination	ILLEGAL	
	L	Н	Н	Н	Х	Х	No Operation	Continue the Burst	
	н	Х	Х	Х	Х	X	Device Deselect	Continue the Burst	

 H
 X
 X
 X
 Device Deselect
 Continue the Burst

1. CKE is assumed to be active (high) in the previous cycle for all entries. The Current State is the state of the bank that the Command is being applied to.

2. Both Banks must be idle; otherwise it is an illegal action.

3. If CKE is active (high), the SDRAM will start the Auto (CBR) Refresh operation. If CKE is inactive (low), then the Self Refresh mode is entered.

4. The Current State only refers to one of the banks. If BS selects this bank, then the action is illegal. If BS selects the bank not being referenced by the Current State, then the action may be legal depending on the state of that bank.

5. If CKE is inactive (low), then the Power Down mode is entered. Otherwise there is a No Operation.

6. The minimum and maximum Active time  $(t_{RAS})$  must be satisfied.

7. The  $\overline{RAS}$  to  $\overline{CAS}$  Delay (t<sub>RCD</sub>) must occur before the command is given.

8. Column address A10 is used to determine if the Auto Precharge function is activated.

9. The command must satisfy any bus contention, bus turn around, and/or write recovery requirements.

10. The command is illegal if the minimum bank to bank delay time ( $t_{\text{RRD}}$ ) is not satisfied.

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.





### Current State Truth Table (Part 3 of 4) (Notes: 1)

0					C	Command		LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL Io Operation; Bank(s) idle after t <sub>RP</sub> Io Operation; Bank(s) idle after t <sub>RP</sub> Io Operation; Bank(s) idle after t <sub>RP</sub> LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL ILEGAL ILEGAL ILEGAL ILEGAL LLEGAL LLEGAL ILEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL LLEGAL	NI-4
Current State	$\overline{\text{CS}}$	RAS	CAS	WE	A11	A10 - A0	Description	Action	Notes
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	Х	Х	Auto or Self Refresh	ILLEGAL	
	L	L	Н	L	BS	х	Precharge	No Operation; Bank(s) idle after $t_{RP}$	
	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Precharging	L	Н	L	L	BS	Column	Write	ILLEGAL	4
	L	Н	L	Н	BS	Column	Read	ILLEGAL	4
	L	Н	н	L	Х	х	Burst Termination	No Operation; Bank(s) idle after $t_{RP}$	
	L	Н	н	Н	Х	X	No Operation	No Operation; Bank(s) idle after t <sub>RP</sub>	**************
	Н	х	х	Х	х	х	Device Deselect	No Operation; Bank(s) idle after t <sub>RP</sub>	
	L	L	L	L	¢	OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	Х	X	Auto or Self Refresh	ILLEGAL	
Row Activating	L	L	н	L	BS	Х	Precharge	ILLEGAL	4
	L	L	н	н	BS	Row Address	Bank Activate	ILLEGAL	4, 10
Row Activating	L	Н	L	L	BS	Column	Write	ILLEGAL	4
	L	Н	L	Н	BS	Column	Read	ILLEGAL	4
	L	н	Н	L	х	Х	Burst Termination	No Operation; Row Active after t <sub>RCD</sub>	
	L	H	н	Н	Х	X	No Operation	No Operation; Row Active after t <sub>RCD</sub>	
	Н	х	х	Х	х	Data X	Device Deselect	No Operation; Row Active after t <sub>RCD</sub>	
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	***************
	L	L	L	Н	х	X	Auto or Self Refresh	ILLEGAL	
	L	L	н	L	BS	Х	Precharge	ILLEGAL	4
	L	L	н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Write Recovering	L	Н	L	L	BS	Column	Write	Start Write; Determine if Auto-Precharge	9
recovering	L	Н	L	Н	BS	Column	Read	Start Read; Determine if Auto-Precharge	9
	L	Н	н	L	Х	х	Burst Termination	No Operation; Row Active after t <sub>DPL</sub>	
2	L	Н	н	н	Х	х	No Operation	No Operation; Row Active after t <sub>DPL</sub>	
	Н	х	х	Х	х	Х	Device Deselect	ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL No Operation; Row Active after t <sub>RCD</sub> No Operation; Row Active after t <sub>RCD</sub> No Operation; Row Active after t <sub>RCD</sub> ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL ILLEGAL Start Write; Determine if Auto-Precharge Start Read; Determine if Auto-Precharge No Operation; Row Active after t <sub>DPL</sub>	

1. CKE is assumed to be active (high) in the previous cycle for all entries. The Current State is the state of the bank that the Command is being applied to.

2. Both Banks must be idle; otherwise it is an illegal action.

3. If CKE is active (high), the SDRAM will start the Auto (CBR) Refresh operation. If CKE is inactive (low), then the Self Refresh mode is entered.

4. The Current State only refers to one of the banks. If BS selects this bank, then the action is illegal. If BS selects the bank not being referenced by the Current State, then the action may be legal depending on the state of that bank.

5. If CKE is inactive (low), then the Power Down mode is entered. Otherwise there is a No Operation.

6. The minimum and maximum Active time ( $t_{RAS}$ ) must be satisfied.

- 7. The  $\overline{\text{RAS}}$  to  $\overline{\text{CAS}}$  Delay (t\_{\text{RCD}}) must occur before the command is given.
- 8. Column address A10 is used to determine if the Auto Precharge function is activated.
- 9. The command must satisfy any bus contention, bus turn around, and/or write recovery requirements.
- 10. The command is illegal if the minimum bank to bank delay time ( $t_{\text{RRD}}$ ) is not satisfied.

et4U.com



#### Current State Truth Table (Part 4 of 4) (Notes: 1)

Current Otota					C	ommand		0 - H	Nato -
Current State	$\overline{\text{CS}}$	RAS	CAS	WE	A11	A10 - A0	Description	Action	Notes
	CS       RAS       CAS       WE       A11       A10 - A0       Description         I       L       L       L       L       L       Vertical       Mode Register Set       ILLEGAL         L       L       L       H       X       X       Auto or Self Refresh       ILLEGAL         L       L       H       L       BS       X       Precharge       ILLEGAL         L       L       H       L       BS       Row Address       Bank Activate       ILLEGAL         L       H       L       BS       Column       Write       ILLEGAL       ILLEGAL         L       H       L       BS       Column       Read       ILLEGAL       ILLEGAL         L       H       L       X       X       No Operation; Precharge after t <sub>DPL</sub> IL         L       H       H       X       X       No Operation; Precharge after t <sub>DPL</sub> No Operation; Precharge after t <sub>DPL</sub> H       X       X       X       Device Deselect       No Operation; Precharge after t <sub>DPL</sub> H       X       X       X       Auto or Self Refresh       ILLEGAL         L       L       L       H       <								
	L	L	L	Н	Х	X	Auto or Self Refresh	ILLEGAL	
	L	L	Н	L	BS	Х	Precharge	ILLEGAL	4
Write	L	L	н	Н	BS	Row Address	Bank Activate	ILLEGAL	4
Recovering with Auto-	L	н	L	L	BS	Column	Write	ILLEGAL	4, 9
Precharge	L	Н	L	Н	BS	Column	Read	ILLEGAL	4, 9
	L	Н	н	L	Х	Х	Burst Termination	No Operation; Precharge after t <sub>DPL</sub>	
	L	Н	н	Н	х	Х	No Operation	No Operation; Precharge after t <sub>DPL</sub>	
	н	х	х	Х	х	X	Device Deselect	No Operation; Precharge after t <sub>DPL</sub>	
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
Refreshing	L	L	L	Н	х	X	Auto or Self Refresh	ILLEGAL	
	L	L	н	L	BS	Х	Precharge	ILLEGAL	
	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	
Refreshing	L	н	L	L	BS	Column	Write	ILLEGAL	
	L	Н	L	Н	BS	Column	Read	ILLEGAL	
	L	н	н	L	Х	Х	Burst Termination	No Operation; Idle after t <sub>RC</sub>	
	L	Н	н	Н	Х	X	No Operation	No Operation; Idle after t <sub>RC</sub>	
	н	х	х	Х	х	X Da	Device Deselect	No Operation; Idle after t <sub>RC</sub>	
	L	L	L	L		OP Code	Mode Register Set	ILLEGAL	
	L	L	L	Н	Х	X	Auto or Self Refresh	ILLEGAL	
	L	L	Н	L	BS	X	Precharge	ILLEGAL	
	L	L	Н	Н	BS	Row Address	Bank Activate	ILLEGAL	
Mode Register Accessing	L	Н	L	L	BS	Column	Write	ILLEGAL	
	L	Н	L	Н	BS	Column	Read	ILLEGAL	
	L	Н	Н	L	Х	Х	Burst Termination	ILLEGAL	
	L	Н	н	Н	Х	X	No Operation	No Operation; Idle after two clock cycles	
	н	Х	Х	Х	х	X	Device Deselect	No Operation; Idle after two clock cycles	

1. CKE is assumed to be active (high) in the previous cycle for all entries. The Current State is the state of the bank that the Command is being applied to.

2. Both Banks must be idle; otherwise it is an illegal action.

3. If CKE is active (high), the SDRAM will start the Auto (CBR) Refresh operation. If CKE is inactive (low), then the Self Refresh mode is entered.

4. The Current State only refers to one of the banks. If BS selects this bank, then the action is illegal. If BS selects the bank not being referenced by the Current State, then the action may be legal depending on the state of that bank.

5. If CKE is inactive (low), then the Power Down mode is entered. Otherwise there is a No Operation.

6. The minimum and maximum Active time ( $t_{RAS}$ ) must be satisfied.

- 7. The RAS to CAS Delay (t<sub>RCD</sub>) must occur before the command is given.
- 8. Column address A10 is used to determine if the Auto Precharge function is activated.
- 9. The command must satisfy any bus contention, bus turn around, and/or write recovery requirements.
- 10. The command is illegal if the minimum bank to bank delay time (t<sub>BBD</sub>) is not satisfied.

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



Page 42 of 121

www.DataSheet4U.com



# **Absolute Maximum Ratings**

Symbol	Parameter	Rating	Units	Notes
VDD	Power Supply Voltage	-1.0 to +4.6	V	1
VDDQ	Power Supply Voltage for Output	-1.0 to +4.6	V	1
V <sub>IN</sub>	Input Voltage	-1.0 to +4.6	V	1
V <sub>OUT</sub>	Output Voltage	-1.0 to +4.6	V	1
T <sub>A</sub>	Operating Temperature (ambient)	0 to +70	°C	1
T <sub>STG</sub>	Storage Temperature	-55 to +125	°C	1
PD	Power Dissipation	1.0	w	1
I <sub>OUT</sub>	Short Circuit Output Current	50	mA	1

 Stresses greater than those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. This is a stress rating only and functional operation of the device at these or any other conditions above those indicated in the operational sections of this specification is not implied. Exposure to absolute maximum rating conditions for extended periods may affect reliability.

# Recommended DC Operating Conditions (T<sub>A</sub>= 0 to 70°C)

Currente e l	Devenue ten		Rating		11-34-	Notes	
Бутвоі	Parameter	Min.	Тур.	Max.	Units		
VDD	Supply Voltage	D <b>a</b> QaShe	et4U.co3n	3.6	V	1	
VDDQ	Supply Voltage for Output	3.0	3.3	3.6	v	1	
V <sub>IH</sub>	Input High Voltage	2.0	—	VDD + 0.3	V	1	
VIL	Input Low Voltage	-0.3	_	0.8	v	1	

DataShee

et4U.com



### $\label{eq:capacitance} \textbf{Capacitance}~(\textbf{T}_{A}\text{=}~25^{\circ}\text{C},~\text{f}\text{=}1\text{MHz},~\textbf{V}_{DD}\text{=}~3.3\text{V}\pm0.3\text{V})$

Symbol	Parameter	Min.	Тур	Max.	Units	Notes				
C <sub>l1</sub>	Input Capacitance (A0 - A11)	2.0	2.7	4.0	pF	1				
C <sub>I2</sub>	Input Capacitance (RAS, CAS, WE, CS, CLK, CKE, DQM)	2.0	2.7	4.0	pF	1				
Co	Output Capacitance (DQ0 - DQ15)	2.0	4.0	5.0	pF	1				
1. Multiply g	1. Multiply given planar values by 2 for 2-High stacked device.									

## DC Electrical Characteristics (T<sub>A</sub>= 0 to +70°C, V<sub>DD</sub>= $3.3V \pm 0.3V$ )

Symbol	Parameter	Min.	Max.	Units
l <sub>i(L)</sub>	Input Leakage Current, any input $(0.0V \le V_{IN} \le 3.6V)$ , All Other Pins Not Under Test = 0V	-1	+1	μA
I <sub>O(L)</sub>	Output Leakage Current ( $D_{OUT}$ is disabled, 0.0V $\leq$ V <sub>OUT</sub> $\leq$ 3.6V)	-1	+1	μA
V <sub>OH</sub>	Output Level (TTL) Output "H" Level Voltage (I <sub>OUT</sub> = -2.0mA)	2.4	VDDQ	v
V <sub>OL</sub>	Output Level (TTL) Output "L" Level Voltage (I <sub>OUT</sub> = +2.0mA)	0.0	0.4	v

et4U.com

DataSheet4U.com

DataSheet4U.com

DataSheet4U.com

www.DataSheet4U.com



#### Standby and Refresh Currents (T<sub>A</sub>= 0 to +70 °C, V<sub>DD</sub>= $3.3V \pm 0.3V$ ) (Notes: 1)

Deremeter	Cumb al	Test Candilian		C	Organizatio	n	l lusita	Notes
Parameter	Symbol	Test Condition		x4	x8	x16	Units mA mA mA mA mA mA mA m	INOTES
Precharge Standby Current in	I <sub>CC1</sub> P	$CKE \le V_{IL}(max), t_{CK} = 7$	15ns	3	3	3	mA	2
Power Down Mode	I <sub>CC1</sub> PS	$CKE \le V_{IL}(max), t_{CK} = Ir$	ıfinity	2	2	2	mA	2
Precharge Standby Current in	I <sub>CC1</sub> N	CKE ≥ $V_{IH}$ (min), $t_{CK}$ = 1 Input Change every 30		25	25	25	mA	CS=High 2
Non-Power Down Mode	I <sub>CC1</sub> NS	CKE ≥ V <sub>IH</sub> (min), t <sub>CK</sub> = In No Input Change	ifinity	10	10	10	mA mA mA mA mA mA mA mA mA mA	2
	I. D	CKE ≤ V <sub>IL</sub> (max), t <sub>CK</sub> = 15ns	-80/-10	3	3	3	mA	3, 11
Active Standby Current in Power Down Mode	I <sub>CC2</sub> P	$CKL \leq V _{L(Max)}, CK = 1505$	-322	2	2	—	mA	11
	I <sub>CC2</sub> PS	$CKE \le V_{IL}(max), t_{CK} = Ir$	ıfinity	2	2	2	mA	4, 11
Active Standby Current in Non-	I <sub>CC2</sub> N	CKE ≥ $V_{IH}$ (min), $t_{CK}$ = 1 Input Change every 30	25	25	25	mA	CS=High 5	
Power Down Mode	I <sub>CC2</sub> NS	CKE ≥ V <sub>IH</sub> (min), t <sub>CK</sub> = In No Input Change	ifinity	15	15	15	mA mA mA mA mA mA mA mA mA mA mA mA	6, 11
		$\overline{CAS} \text{ Latency} = 1 \\ t_{RC} \ge t_{RC}(min)$	-10	85	85	85	mA	
			-80	110	110	110		
		CAS Latency = 2 t <sub>RC</sub> ≥ t <sub>RC</sub> (min)	-322	90	90	90	mΔ	7, 8, 9,
Auto (CBR) Refresh Current	I <sub>CC3</sub>	DataSheet4U	-10 com	90	90	90		10
			-80	140	140	140		
		CAS Latency = 3 t <sub>RC</sub> ≥ t <sub>RC</sub> (min)	-322	140	140	140		
			-10	110	110	110	IIIA	
Self Refresh Current	1	CKE ≤ 0.2V	-80/-10	2	2	2	mA	2
	I <sub>CC4</sub>		-322	400	400	—	μA	

1. For stacked devices: only one deck may be active at a time, except during self refresh.

2. For stacked devices: multiply the given planar (individual deck) values by 2.

3. For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (I<sub>CC2</sub>P + I<sub>CC1</sub>P).

 For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (I<sub>CC2</sub>PS + I<sub>CC1</sub>PS).

 For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (I<sub>CC2</sub>N + I<sub>CC1</sub>N).

 For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (I<sub>CC2</sub>NS+ I<sub>CC1</sub>NS).

7. For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (I<sub>CC3</sub> + I<sub>CC1</sub>N).

8. The specified values are valid when addresses are changed no more than once during  $t_{CK}(min)$ .

9. The specified values are valid when No Operation commands are registered on every rising clock edge during  $t_{RC}(min)$ .

10. The specified values are valid when data inputs (DQs) are stable during  $t_{RC}(min)$ .

11. Active Standby Current will be higher if Clock Suspend is entered during a burst read cycle (add 1mA per DQ).

et4U.com

DataSheet4U.com



DataShee

#### **Operating Currents** (T<sub>A</sub>= 0 to +70°C, V<sub>DD</sub>= $3.3V \pm 0.3V$ )

Symbol	Parameter	Test Condition	CAS	t <sub>RC</sub> (min)	Speed	(	Organizatio	n	Units	Notes
Symbol	Falametei		Latency	'RC(IIIII)	Sort	X4	X8	X16	Units	notes
			CL=1	90 ns	-10	95	95	95	mA	
			9 9 9 9 9 9 9 9 9	72 ns	-80	130	130	135		4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4
		t <sub>BC</sub> = t <sub>BC</sub> (min)	CL=2	90 ns	-322	105	105	110	mA	
$I_{CC5}$	Operating Current Burst Length = 1	$t_{CK} \ge t_{CK}(min)$		90 ns	-10	105	105	110		1, 2, 3
		I <sub>O</sub> = 0mA		72 ns	-80	155	155	160		
			CL=3	70 ns	-322	160	160	170	mA	
				90 ns	-10	125	125	130		
			CL=1	120 ns	-10	75	75	80	mA	
				84 ns	-80	125	125	130		
		t <sub>BC</sub> = t <sub>BC</sub> (min)	CL=2	105 ns	-322	100	100	105	mA mA	9 4 4 4 4 4 5 5 5 5 5 5 5 5 5 5 5 5 5 5
I <sub>CC6</sub>	Operating Current Burst Length = 2	$t_{CK} \ge t_{CK}(min)$ $I_{O} = 0mA$		105 ns	-10	100	100	105		1, 2, 3, 4
				80 ns	-80	155	155	160		т
			CL=3	80 ns	-322	155	155	160		
				100 ns	-10	125	125	130		9 9 9 9 9 9 9 9 9 9 9 9 9
			CL=1	180 ns	-10	65	65	70	mA	
				108 ns	-80	115	120	125		
		t <sub>BC</sub> = t <sub>BC</sub> (min)	CL=2	135 ns	-322	90	95	100	mA	
I <sub>CC7</sub>	Operating Current Burst Length = 4	$t_{CK} \ge t_{CK}(min)$		135 ns	-10	90	95	100		1, 2, 3, 4
	Barot Longin – +	l <sub>O</sub> = 0mA	Datas	5h 96 ns	con <sub>80</sub>	150	155	160		
			CL=3	100 ns	-322	145	150	160	mA	
			6 6 8 8 9 9 9 9 8 8 8 8 8	120 ns	-10	120	125	130		
			CL=1	300 ns	-10	55	60	65	mA	
				156 ns	-80	105	110	120		
		t <sub>BC</sub> = t <sub>BC</sub> (min)	CL=2	195 ns	-322	85	90	100	mA	
I <sub>CC8</sub>	Operating Current Burst Length = 8	$t_{CK} \ge t_{CK}(min)$		195 ns	-10	85	90	100		1, 2, 3, 4
	Esist Longin – U	I <sub>O</sub> = 0mA			-80	150	155	165		-
			CL=3	140 ns	-322	140	145	155	mA	*
				160 ns	-10	120	125	135	]	

DataShee

1. The specified values are obtained with the output open.

2. The specified values are valid when addresses and DQs are changed no more than once during  $t_{CK}$ (min).

3. For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (Operating Current+ I<sub>CC1</sub>N).

4. The specified values are obtained when the programmed burst length is executed to completion without interruption by a subsequent burst Read or Write cycle.

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com



Page 46 of 121



### **Operating Currents** (T<sub>A</sub>= 0 to +70°C, V<sub>DD</sub>= $3.3V \pm 0.3V$ )

Sumbol	Parameter	Test Condition	CAS	t <sub>RC</sub> (min)	Speed	C	Organizatio	n	Units	Notes																	
Symbol	Farameter	Test Condition	Latency	'RC(IIIII)	Śort	X4	X8	X16	Units	notes																	
			CL=1	t <sub>RC</sub> = ∞ t <sub>CK</sub> =30 ns	-10	40	45	55	mA																		
				t <sub>RC</sub> = ∞ t <sub>CK</sub> =12 ns	-80	90	95	110																			
				t <sub>RC</sub> = ∞ t <sub>CK</sub> =15 ns	-322	70	75	90	mA																		
I <sub>CC9</sub>	Operating Current Burst Length = Full Page	t <sub>RC</sub> = Infinity t <sub>CK</sub> ≥ t <sub>CK</sub> (min) I <sub>O</sub> = 0mA		t <sub>RC</sub> = ∞ t <sub>CK</sub> =15 ns	-10	70	75	90		1, 2, 3, 4																	
	Ŭ	0		t <sub>RC</sub> = ∞ t <sub>CK</sub> =8 ns	-80	125	130	170																			
				CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	CL=3	t <sub>RC</sub> = ∞ t <sub>CK</sub> =10 ns	-322	100	105	135	mA
								t <sub>RC</sub> = ∞ t <sub>CK</sub> =10 ns	-10	100	105	135															
			CL=1	t <sub>RC</sub> = ∞ t <sub>CK</sub> =30 ns	-10	85	85	90	mA																		
				t <sub>RC</sub> = ∞ t <sub>CK</sub> =12ns	-80	165	165	175																			
	Operating Current 1-N Rule	1 1 6 11	CL=2	t <sub>RC</sub> = ∞ t <sub>CK</sub> =15 ns	-322	130	130	140	mA																		
I <sub>CC10</sub>	(Continuous Read/Write cycles with new column	$\begin{array}{l} t_{\rm RC} = {\rm Infinity} \\ t_{\rm CK} \geq t_{\rm CK}({\rm min}) \\ {\rm I}_{\rm O} = {\rm OmA} \end{array}$	DataShe	t <sub>RC</sub> = ∞ etck+15.ns)	n -10	130	130	140		1, 2, 3																	
	address registered each clock cycle)					t <sub>RC</sub> = ∞ t <sub>CK</sub> =8 ns	-80	220	220	240																	
				CL=3	t <sub>RC</sub> = ∞ t <sub>CK</sub> =10 ns	-322	175	175	190	mA																	
				t <sub>RC</sub> = ∞ t <sub>CK</sub> =10 ns	-10	175	175	190																			

1. The specified values are obtained with the output open.

2. The specified values are valid when addresses and DQs are changed no more than once during  $t_{CK}(min)$ .

3. For stacked devices: this is the active portion only. The total stack current includes the Precharge Standby current of the inactive deck (Operating Current+ I<sub>CC1</sub>N).

4. The specified values are obtained when the programmed burst length is executed to completion without interruption by a subsequent burst Read or Write cycle.

et4U.com



www.DataSheet4U.com

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



#### AC Characteristics ( $T_A = 0$ to +70°C, $V_{DD} = 3.3V \pm 0.3V$ )

- 1. An initial pause of 100µs is required after power-up, then a Precharge All Banks command must be given followed by a minimum of two Auto (CBR) Refresh cycles before the Mode Register Set operation can begin.
- 2. The Transition time is measured between V\_{IH} and V\_{IL} (or between V\_{IL} and V\_{IH}).
- 3. In addition to meeting the transition rate specification, the clock and CKE must transit between V<sub>IH</sub> and V<sub>IL</sub> (or between V<sub>IL</sub> and V<sub>IH</sub>) in a monotonic manner.
- 4. AC timing tests have  $V_{IL}$  = 0.4 V and  $V_{IH}$  = 2.4 V with the timing referenced to the 1.40V crossover point.
- 5. AC measurements assume  $t_T=1.0$  ns.



DataShee

### **Clock and Clock Enable Parameters**

C: make al	Devementer		-80		-322		-10	Links	Nistes
Symbol	Parameter	Min.	Max.	Min.	Max.	Min.	Max.	Units	Notes
t <sub>CK3</sub>	Clock Cycle Time, CAS Latency=3	8	125MHz	10	100MHz	10	100MHz	ns	
t <sub>CK2</sub>	Clock Cycle Time, CAS Latency=2	12	83MHz	15	66MHz	15	66MHz	ns	
t <sub>CK1</sub>	Clock Cycle Time, CAS Latency=1	-	—	—	—	30	33MHz	ns	
t <sub>AC3</sub>	Clock Access Time, CAS Latency=3	—	6	—	6	—	8	ns	1, 2
t <sub>AC2</sub>	Clock Access Time, CAS Latency=2	—	7	—	9	—	9	ns	1, 2
t <sub>AC1</sub>	Clock Access Time, CAS Latency=1	—	—	—	_	—	27	ns	1, 2
t <sub>скн</sub>	Clock High Pulse Width	3	—	3	—	3.5	—	ns	3
t <sub>CKL</sub>	Clock Low Pulse Width	3	—	3	—	3.5	—	ns	3
t <sub>CES</sub>	Clock Enable Set-up Time	2	—	2	_	3	—	ns	
t <sub>CEH</sub>	Clock Enable Hold Time	1	—	1	—	1	—	ns	
t <sub>CESP</sub>	CKE Set-up Time (Power down mode)	2	—	2	_	3	—	ns	
t <sub>T</sub>	Transition Time (Rise and Fall)	1	30	1	30	1	30	ns	

1. Access time is measured at 1.4V. See AC Characteristics: notes 1,2,3,4,5 and load circuit.

2. Access time is measured assuming a clock rise time of 1 ns. If clock rise time is longer than 1 ns, then (trise/2-0.5)ns should be added to the parameter.

3. Assumes clock rise and fall times are equal to 1 ns. If rise or fall time exceeds 1 ns, then other AC parameters under consideration should be compensated by an additional [(trise+tfall)/2-1]ns.

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 48 of 121



## **Common Parameters**

0	D	-	80	-:	322	-	10	1194
Symbol	Parameter	Min.	Max.	Min.	Max.	Min.	Max.	Units
t <sub>cs</sub>	Command Setup Time	2	—	2	—	3	—	ns
t <sub>CH</sub>	Command Hold Time	1	—	1	—	1	—	ns
t <sub>AS</sub>	Address and Bank Select Set-up Time	2	_	2	—	3	—	ns
t <sub>AH</sub>	Address and Bank Select Hold Time	1	—	1	—	1	—	ns
t <sub>RCD</sub>	RAS to CAS Delay	24	—	20	—	30	—	ns
t <sub>RC</sub>	Bank Cycle Time	72	120K	70	120K	90	120K	ns
t <sub>RAS</sub>	Active Command Period	48	120K	50	120K	60	120K	ns
t <sub>RP</sub>	Precharge Time	24	—	20	—	30	—	ns
t <sub>RRD</sub>	Bank to Bank Delay Time	16	—	20	—	20	—	ns
t <sub>CCD</sub>	CAS to CAS Delay Time (Same Bank)	1	—	1	—	1	—	CLK

# **Refresh Cycle**

	-80 -322		322	-10		Units	Nataa		
Symbol	Parameter	Min.	Max.	Min.	Max.	Min.	Max.		NOLES
t <sub>REF</sub>	Refresh Period DataSt	neet4U	64		64	—	64	ms	1, 2
t <sub>srex</sub>	Self Refresh Exit Time	10ns + t <sub>RC</sub>	_	10ns + t <sub>RC</sub>	—	10ns + t <sub>RC</sub>	—	ns	3

DataShee

1. 4096 cycles.

2. Any time that the Refresh Period has been exceeded, a minimum of two Auto (CBR) Refresh commands must be given to "wakeup" the device.

3. Self Refresh Exit is an asynchronous operation. Self refresh exit is accomplished by starting the clock (CLK) and then asserting CKE high. During the exit time (t<sub>SREX</sub>), no commands may be issued until t<sub>RC</sub> is satisfied and CKE must remain high. It is recommended to hold CS high during the self refresh exit time, but NOP commands may be issued with each rising clock edge during this period as an alternative. To prevent erroneous exit of self refresh operation, a glitch suppressor circuit is incorporated into the CKE receiver. If CKE is asserted high (system noise) for less than 10ns (approximately), then the device will not exit self refresh operation.

# **Read Cycle**

O	Development	-80		-322		-10		Linite	NI-1
Symbol	Parameter	Min.	Max.	Min.	Max.	Min.	Max.	Units	Notes
t <sub>он</sub>	Data Out Hold Time	2.5	—	3	—	3	—	ns	
t∟z	Data Out to Low Impedance Time	2.5	—	2.5	—	3	—	ns	
t <sub>HZ3</sub>	Data Out to High Impedance Time,CL= 3	2.5	8	2.5	8	3	8	ns	1
t <sub>HZ2</sub>	Data Out to High Impedance Time,CL= 2	2.5	8	2.5	8	3	10	ns	1
t <sub>HZ1</sub>	Data Out to High Impedance Time,CL= 1	—	—	—	—	3	18	ns	1
t <sub>DQZ</sub>	DQM Data Out Disable Latency	2	_	2	—	2	—	CLK	

1. Referenced to the time at which the output achieves the open circuit condition, not to output voltage levels.

DataSheet4U.com

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



# Write Cycle

Sumbol	Symbol Parameter		-80		-322		-10		Notes
Symbol	Falametei	Min.	Max.	Min.	Max.	Min.	Max.	Units	NOLES
t <sub>DS</sub>	Data In Set-up Time	2	—	2	—	3	—	ns	
t <sub>DH</sub>	Data In Hold Time	1	—	1	—	1	—	ns	
t <sub>DPL</sub>	Data Input to Precharge	8	—	15	—	10	—	ns	
t <sub>DQW</sub>	DQM Write Mask Latency	0	—	0	—	0	—	CLK	

et4U.com

DataShee

DataSheet4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 50 of 121

DataSheet4U.com



# **Clock Frequency and Latency**

Symbol	Parameter	-8	30	-3	22		-10		Units
fCK	Clock Frequency	125	83	100	66	100	66	33	MHz
t <sub>CK</sub>	Clock Cycle Time	8	12	10	15	10	15	30	ns
t <sub>AA</sub>	CAS Latency	3	2	3	2	3	2	1	CLK
t <sub>RCD</sub>	RAS to CAS Delay	3	2	2	2	3	2	1	CLK
t <sub>RL</sub>	RAS Latency	6	4	5	4	6	4	2	CLK
t <sub>RC</sub>	Bank Cycle Time	9	6	7	6	9	6	3	CLK
t <sub>RAS</sub>	Minimum Bank Active Time	6	4	5	4	6	4	2	CLK
t <sub>RP</sub>	Precharge Time	3	2	2	2	3	2	1	CLK
t <sub>DPL</sub>	Data In to Precharge	1	1	2	1	1	1	1	CLK
t <sub>DAL</sub>	Data In to Active/Refresh	4	3	4	3	4	3	2	CLK
t <sub>RRD</sub>	Bank to Bank Delay Time	2	2	2	2	2	2	1	CLK
t <sub>CCD</sub>	CAS to CAS Delay Time	1	1	1	1	1	1	1	CLK
t <sub>WL</sub>	Write Latency	0	0	0	0	0	0	0	CLK
t <sub>DQW</sub>	DQM Write Mask Latency	0	0	0	0	0	0	0	CLK
t <sub>DQZ</sub>	DQM Data Disable Latency	2	2	2	2	2	2	2	CLK
t <sub>CSL</sub>	Clock Suspend Latency	neet4U.con	1	1	1	1	1	1	CLK

DataShee

DataSheet4U.com

et4U.com



et4U.com

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D

# **Timing Diagrams**

AC Parameters for Read Timing	. 56
Mode Register Set	. 57
Power on Sequence and Auto Refresh (CBR)	. 58
Clock Suspension During a Burst Read (Using CKE)	
CAS Latency = 1	. 59
CAS Latency = 2	. 60
CAS Latency = 3, t <sub>RCD</sub> = 3	. 61
Clock Suspension During a Burst Write (Using CKE)	
CAS Latency = 1	. 62
CAS Latency = 2	. 63
CAS Latency = 3, t <sub>RCD</sub> = 3	. 64
Power Down Mode and Clock Suspend	. 65
Auto Refresh (CBR)	. 66
Self Refresh (Entry and Exit)	. 67
Random Column Read (Page within same Bank)	
CAS Latency = 1DataSheet4U.com	. 68
CAS Latency = 2	. 69
$\overline{CAS}$ Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	. 70
$\overline{CAS}$ Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 2	.71
Random Column Write (Page within same Bank)	
CAS Latency = 1	. 72
CAS Latency = 2	. 73
$\overline{CAS}$ Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3, t <sub>DPL</sub> = 1	. 74
$\overline{CAS}$ Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 2, t <sub>DPL</sub> = 2	. 75
Random Row Read (Interleaving Banks)	
CAS Latency = 1	. 76
CAS Latency = 2	. 77
CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	. 78



Page

Preliminary (-80,-322)

DataShee

www.DataSheet4U.com

DataSheet4U.com

Preliminary (-80,-322)

# **Timing Diagrams**

# Page

Random Rov	w Write (Interleaving Banks)	
	CAS Latency = 1	
	CAS Latency = 2	80
	CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	
Read And W	/rite Cycle	
	CAS Latency = 1	
	CAS Latency = 2	
	$\overline{CAS}$ Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	
Interleaved (	Column Read Cycle	
	CAS Latency = 1	
	CAS Latency = 2	
	CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	
Interleaved (	Column Write Cycle	
	CAS Latency = 1	
	CAS Latency = 2	
	$\overline{CAS}$ Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3, t <sub>DPL</sub> = 1	
	CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 2,t <sub>DP</sub> 1 ≅2↓U.com	
Auto-Precha	arge after a Read Burst	
	CAS Latency = 1	
	CAS Latency = 2	
	CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	
Auto-Precha	arge after a Write Burst	
	CAS Latency = 1	
	CAS Latency = 2	
	CAS       Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	
Full Page Re	ead Cycle	
	CAS Latency = 1	
	CAS Latency = 2	
	CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	100

DataSheet4U.com

et4U.com



et4U.com

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D

# **Timing Diag**

DataSheet4U.com



•	
Timing Diagrams	Page
Full Page Write Cycle	
CAS Latency = 1	
CAS Latency = 2	
CAS Latency = 3, t <sub>RCD</sub> , t <sub>RP</sub> = 3	
Byte Write Operation	
Burst Read and Single Write Operation	
Full Page Burst Read and Single Write Operation	
Random Row Read (Interleaving Banks)	107
Full Page Random Column Read	
Full Page Random Column Write	
Prochargo Termination of a Rurat	

Precharge Termination of a Burst CAS Latency = 3, t<sub>BCD</sub>, t<sub>BP</sub> = 2, t<sub>DPL</sub> = 2......113 

DataShe





Preliminary (-80,-322)





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



Preliminary (-80,-322)



et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 56 of 121

Preliminary (-80,-322)



DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.





et4U.com

Powe

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com



DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

et4U.com

www.DataSheet4U.com

Ī

Preliminary (-80,-322)

DataSheet4U.com



DataSheet4U.com

Image BM Corporation. All rights reserved.
Use is further subject to the provisions at the end of this document.

www.DataSheet4U.com

DataShee

IBM03164B9C

IBM0316409C IBM0316809C IBM0316169C

16Mb Synchronous DRAM-Die Revision D

www.DataSheet4U.com



DataSheet4U.com

Page 60 of 121





08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. DataShee

I





et4U.com

www.DataSheet4U.com

DataShee

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

CKE

S

<u>RAS</u>

CAS

MΕ

A11(BS)

CLK

www.DataSheet4U.com

A0 - A9

DQM

ğ

A10

Page 62 of 121



DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Ī

Preliminary (-80,-322)



IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



Page 64 of 121

Use is further subject to the provisions at the end of this document.

08J3348 GA15-5285-04 1/98

**IBW** Preliminary (-80,-322)



DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D





DataShee

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com



Page 66 of 121



DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataShee

www.DataSheet4U.com

Ī

Preliminary (-80,-322)



et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShe

Page 68 of 121

Ξ

Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



DataShee

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Preliminary (-80,-322)

Page 70 of 121

Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D





DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShe

et4U.com

Page 72 of 121
Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



DataShee

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Preliminary (-80,-322)

Page 74 of 121

Ξ

Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 76 of 121



Preliminary (-80,-322)



DataSheet4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataShe

www.DataSheet4U.com



DataShee

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Preliminary (-80,-322)

Page 78 of 121





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



Preliminary (-80,-322)

DataShee

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Page 80 of 121





DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



Preliminary (-80,-322)



DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 82 of 121

Ī

Preliminary (-80,-322)





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



DataShee

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Preliminary (-80,-322)

Page 84 of 121

Preliminary (-80,-322)





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.





et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 86 of 121

Preliminary (-80,-322)



DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.





DataShee

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Page 88 of 121

Preliminary (-80,-322)



DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved.

DataShee

Use is further subject to the provisions at the end of this document.



DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee



DataSheet4U.com

Page 90 of 121







DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



Burst Length = 4, <u>CAS</u> Latency = 1 T22 Bz3 **T**21 Bz2 Start Auto-Precharge Bank B T20 Bz1 T19  $\mathbb{B}_{z0}$ Activate Command Bank B Read with Auto-Precharge Command Bank B T18 RBZ CBZ T15 T16 T17 RBz By3 By2 Start Auto-Precharge Bank B Ay1 X Ay2 X Ay3 X By0 X By1 X T13 T14 Read with Auto-Precharge Command Bank B CBV T11 T12 Start Auto-Precharge Bank A Activate Activate Command Bank B Read with Auto-Precharge Command Bank A **T**10 Bx2 X Bx3 X Ay0 X By ۴ **T**8 Start Auto-Precharge Bank B 4 Bx1 X **T**6 Bx0 X Auto-Precharge after Read Burst (1 of 3) Activate Command Bank B Auto-Precharge Command Bank B **1**5 Ax1 X Ax2 X Ax3 > 4 (XBX) Ξ ř Ax0 t<sub>cK1</sub> Read Command Bank A F Krax Cax Activate Command Bank A ۴ (RAX) H-Z High A0 - A9 A10 CLK CKE S RAS CAS ME A11(BS) DQM ğ

et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

M

Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved.

Use is further subject to the provisions at the end of this document.

www.DataSheet4U.com



DataSheet4U.com

Page 94 of 121

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

08J3348 GA15-5285-04 1/98

Preliminary (-80,-322)





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

www.DataSheet4U.com



et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

# Page 96 of 121



Preliminary (-80,-322)

M

Preliminary (-80,-322)



DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



DataShe

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Preliminary (-80,-322)

Page 98 of 121

Ξ /

Preliminary (-80,-322)



DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



DataShe

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Page 100 of 121

Ξ Έ

Preliminary (-80,-322)





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.





DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 102 of 121

Ξ Έ

Preliminary (-80,-322)



DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved.

Use is further subject to the provisions at the end of this document.





et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 104 of 121

Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.



et4U.com

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee



Preliminary (-80,-322)



et4U.com

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

DataShee

www.DataSheet4U.com





DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 108 of 121
M

Preliminary (-80,-322)





DataSheet4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 109 of 121

et4U.com



DataShe

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com



Preliminary (-80,-322)

Page 110 of 121





DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D





DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

DataShee

Page 112 of 121

Preliminary (-80,-322)



DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

#### IBM0316409C IBM0316809C IBM0316169C IBM03164B9C 16Mb Synchronous DRAM-Die Revision D



Preliminary (-80,-322)



DataShee

DataSheet4U.com

et4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. www.DataSheet4U.com

Page 114 of 121



### PACKAGE DIMENSIONS (400mil; 44 lead; Thin Small Outline Package)



et4U.com

DataSheet4U.com



Detail A 0.25 Basic Gage Plane 0.05 Min 0.5 ± 0.1

NOTE: All dimensions are in millimeters; Package Diagrams are not drawn to scale.

DataSheet4U.com

08J3348 GA15-5285-04 1/98 ©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

Page 115 of 121

www.DataSheet4U.com

DataShe

IBM0316409C IBM0316809C IBM0316169C IBM03164B9C **16Mb Synchronous DRAM-Die Revision D** 



#### PACKAGE DIMENSIONS (400mil; 50 lead; Thin Small Outline Package)



et4U.com

DataSheet4U.com





NOTE: All dimensions are in millimeters; Package Diagrams are not drawn to scale.

DataSheet4U.com

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document. DataShe

Page 116 of 121



# PACKAGE DIMENSIONS (400mil; 44 lead; 2 High Stack; Thin Small Outline J Lead Package)





NOTE: All dimensions are in millimeters; Package Diagrams are not drawn to scale.

DataSheet4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

www.DataSheet4U.com

DataShe



# **Revision Log**

Revision	Contents Of Modification		
11/14/97	Initial Release (Preliminary)		
5/16/97	page 20	Correction to Auto-precharge description/diagram notes. (Page 23, 24)	
	page 50	Change t <sub>DPL</sub> from 8ns to 10ns for -10.	
	page 67	Correct CKE transition.	
	page 45	Correction of note regarding total stack current (CBR current).	
	page 25	Precharge Termination changed (now similar to burst stop).	
	page 26		
	page 29		
	page 30		
	page 66	Correct WE - Read Command.	
	page 70	Precharge Termination changed: precharge and subsequent commands 1 clock sooner.	
	page 70	Correct A10 - Precharge Command A.	
7/14/97	page 87	Precharge Termination changed: last precharge 1 clock sooner.	
	page 95	Fix numbering of data - address Az.	
	page 96	Fix numbering of data - address Az.	
	page 98	Correct A10 - Read Command.	
	page 101	Correct A10 - first Write Command.eet4U.com	
	page 110	Correct A10 - Write and Read Commands.	
	page 112	Precharge Termination: number of data bits after command changed.	
	page 113	Precharge Termination: number of data bits after command changed.	
8/21/97	page 45	Add note to I <sub>CC2</sub> NS.	

DataShee

DataSheet4U.com

et4U.com

DataSheet4U.com

Page 118 of 121



## **Revision Log**

		×
	page 1	Remove -7, -8; Add -322, -90. Remove low power SR. Change max. data rate.
	page 2	Remove Vara remove part numbers
	page 3	Remove V <sub>REF</sub> , remove part numbers.
	page 4	Remove V <sub>REF</sub> .
	page 5	Change part number information.
	page 6	Remove V <sub>REF</sub> . (Also, page 7 - page 9.)
	page 10	Remove V <sub>REF</sub> in Power On description.
	page 14	Change max. data rate.
10/08/97	page 43	Remove SSTL_3 Recommended DC Operating conditions.
	page 44	Remove SSTL_3 Output Characteristics.
	page 45	Change currents - different speed sorts.
	page 46	Change currents - different speed sorts.
	page 48	
	page 49	Remove -7, -8; Add -322, -90.
	page 50	
	page 51	Change speed sorts.
	page 55	Correct address (Page 55 also).
	page 1	Remove x8 stack. Add Column address clarification. Add note to performance table.
	page 3	Remove x8 stack.
	page 5	Update ordering information.
	page 9	Remove x8 stack.
	page 22	Change diagrams.
	page 26	Change/ add diagram.
	page 28	Change diagram.
	page 30	Change/ add diagram.
11/14/97	page 31	Change text (t <sub>DPL</sub> ).
	page 32	Change diagram/ text (t <sub>DPL</sub> ).
	page 45	Specify -322 I <sub>CC2P</sub> , I <sub>CC4</sub> currents.
	page 48	Change notes for AC Characteristics and Clock and Clock Enable Parameters tables ( $V_{IH}$ , $V_{IL}$ , $t_T$ ).
	page 52	Correct/ clarify titles.
	page 71	Add timing diagram: Random column read, CL=3, $t_{RCD}/t_{RP} = 2$ .
	page 75	Change diagram.
	page 91	
	page 113	

DataSheet4U.com

et4U.com

08J3348 GA15-5285-04 1/98

©IBM Corporation. All rights reserved. Use is further subject to the provisions at the end of this document.

www.DataSheet4U.com



Preliminary (-80,-322)

### **Revision Log**

1/05/98	page 1	Update speed sort information: remove -90, add -80. Also, page 5, page 14, page 45, page 46, page 48 - page 51.
	page 21	Update Auto-precharge description.
	page 22	Add diagrams showing Auto-precharge Interrupt. Also, page 23, page 24.
	page 26	Change -90 to -80 or add -80. Also, page 28, page 30.
	page 35	Update Power Down Mode description. Also, page 37.
	page 39	Update Read/Write with Auto-precharge notes.
	page 67	Correct address inputs.
	page 74	Add t <sub>DPL</sub> clarification. Also, page 75, page 90, page 91, page 113.

et4U.com

DataSheet4U.com

DataShee

DataSheet4U.com

Page 120 of 121

www.DataSheet4U.com



© International Business Machines Corp.1998

Printed in the United States of America All rights reserved

IBM and the IBM logo are registered trademarks of the IBM Corporation.

This document may contain preliminary information and is subject to change by IBM without notice. IBM assumes no responsibility or liability for any use of the information contained herein. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of IBM or third parties. The products described in this document are not intended for use in implantation or other direct life support applications where malfunction may result in direct physical harm or injury to persons. NO WARRANTIES OF ANY KIND, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE OFFERED IN THIS DOCUMENT.

	For more information contact your IBM Microelectronics sales representative or
et4U.com	visit us on World Wide Web at http://www.chips.ibm.com

IBM Microelectronics manufacturing is ISO 9000 compliant.

www.DataSheet4U.com